

# SERVICE HINT

**CONCERNING: Service Codes for PP KIRK 3040, KIRK 40XX & KIRK 5020.**

Some of the given codes might not be active as the level of service codes implemented is depending on the hardware & software status of the handset.

## **KIRK 3040**

- \*99950\* - Delete Phone Book – Redial Stack /Clip Stack – Mail Stack – All Subscriptions
- \*99951\* - Delete Phone Book
- \*99952\* - Delete Redial/Clip Stack
- \*99953\* - Delete Mail Stack
- \*99954\* - Delete all Subscriptions
- \*99968\* - Enable B-answer when placed in charger
- \*99977\* - Vibrator, buzzer and display test
- \*99981\* - Test Display – old type
- \*99982\* - Read back of software part number & edition
- \*99984\* - Read back of serial number to display
- \*99985\* - Read back of battery capacity/Voltage
- \*99989\* - Test Display for measuring radio performance/coverage
- \*\*\*\*/Redial – Read back serial number to display

## **KIRK 40xx**

- \*99950\* - Delete phone book, redial stack, clip stack, mail stack and all subscriptions
- \*99951\* - Delete phone book
- \*99952\* - Delete redial and clip stack
- \*99953\* - Delete mail stack
- \*99954\* - Delete all subscriptions
- \*99977\* - Vibrator, Loudspeaker and display test (Loudspeaker only KIRK 4040/4080)
- \*99981\* - Test Display – old type
- \*99982\* - Read back of software part number & edition
- \*99984\* - Displays the handset item number, serial number, production week/year, hardware PCS and Software part number and edition
- \*99989\* - Test Display for measuring radio performance/coverage
- \*\*\*\*/Redial – Read back serial number to display

## **KIRK 4020**

- \*99977\*1 - Vibrator, buzzer and display test

## **KIRK 5020**

Some of the given codes might not be active as the level of service codes implemented is depending on the hardware & software status of the handset.

To enter a Service Code - enter the requested code and press OFF-HOOK key.

- \*99950\* - Delete phone book, speed dial list, message templates and all subscriptions
- \*99951\* - Delete Phonebook and speed dial list
- \*99954\* - Delete all subscriptions
- \*99968\* - Enable B-answer when placed in charger
- \*99977\* - Vibrator, buzzer and display test
- \*99988\* - Show handset up-time
- \*99989\* - Test display for measuring radio performance/coverage